Assembling Instruction

Ax1 	Fx5 
Bx2 	Gx4  short screws
Cx1 	Hx4  long screws
Dx1 	Ix4 
Ex1 	Jx4 
Kx2 	Use to set screws

⚠WARNING !
Please remove the plastic cap before assembly-











